

pBUZZ®

Care card



pBuzz Customer Care Card

Includes how to play, sheet music, product care information & warranty details

Thank you for purchasing pBuzz. We hope you and your family have many hours of fun – that's why we created it! Here are a few tips to help get you started.

How to play

- Buzz:** Position the mouthpiece in the middle of your lips, create a hole in your lips and blow air through it. Slowly make the hole smaller as you blow to create a buzz - watch at: www.bit.ly/2y0Qlzy
- Slide:** The moveable slide has six notes or slide positions: 1 – 6 or F, G, A, B, Bb, C. See Chris talking about how to move the slide at <https://youtu.be/eKfbupivFBC>
- Making a note:** Slide the bell towards you to create a high note and away from you to create a low note

There are lots of training videos for children, parents and teachers online which will also help you get started. Please look at www.pbuzz.co.uk/how-to-play/ or our YouTube Channels below.

Sheet music and backing tracks

Please check out the easy colour-coded sheet music tunes at the end of this booklet with online backing videos available from www.bit.ly/2w8pzVc

Of course feel free to play along to any music you like – from your own playlists, radio, TV, and even just playing simple rhythms on a one or two notes. Have fun!

Cleaning

pBuzz is completely made from plastic, making it very durable and robust – which means it is safe to use and easy to clean.

To clean the external red surfaces, use a soft cloth with warm soapy water and dry the instrument with a lint free cloth. We recommend that you clean the instrument before first use, being careful not to get soapy water on the clear tube as this may damage the coloured paper insert.

We do not recommend placing or immersing the pBuzz fully in water as this can damage the coloured-paper insert sleeve inside the clear plastic tube. If you do need a replacement coloured-paper insert please email us info@pbuzz.co.uk

pBone®

www.pbone.co.uk

 /pBoneOfficial

 @pBoneOfficial

 /pBoneUK

 /pBoneOfficial

pTrumpet®

www.ptumpet.com

 /thepTrumpet


 @thepTrumpet

 /theptrumpet

 /theptrumpet

pBuzz®

www.pbuzz.co.uk

 /pBuzzMusic

 @pBuzzMusic

 /pBuzz

Mouthpiece

The pBuzz mouthpiece has an embedded anti-microbial from BioCote® which kills 99% of germs within 15 minutes. You can clean the pBuzz mouthpiece fully in warm soapy water and even put pBuzz mouthpieces in the dishwasher for cleaning!

If your mouthpiece is stuck, run the red part of the mouthpiece receiver under hot tap water to allow the outer to expand, taking care not to get the insert wet. Then carefully pull the mouthpiece out.

Disassembling the pBuzz or replacing the coloured paper insert

To disassemble the pBuzz follow these simple steps:

1. Remove the mouthpiece
2. Remove the black rubber washer – be careful not to let the middle pipe fall on the floor as you remove the washer
3. Carefully push the middle pipe through the bottom of the bell – you will now have 2 separate sections.
4. You can gently click upwards the top of the clear plastic cover to reveal the paper insert
5. To re-assemble pBuzz reverse steps 4 through 1

Storage

We recommend standing pBuzz vertically on its bell with the mouthpiece in the top. Be careful that the mouthpiece is not pushed too hard into the receiver.

Take care not to store pBuzz in locations such as:

- Locations exposed to direct sunlight;
- Close to naked flames from sources such as cooking stoves;
- Locations affected by flowing water or rain;
- Locations with high humidity; or
- Locations with high levels of dust or dirt

There is also available to buy a separate pBuzz pouch with elasticated straps for easy carrying from <http://shop.pbone.co.uk/>



We love to hear from you

Our pPals support team loves hearing from pBuzz players. Please don't hesitate to contact us with any further questions or feedback via social media or email info@pbuzz.co.uk or contact your local pBuzz dealer.

Uses notes F G A C

Mary Had A Little Lamb

Ma - ry had a li - ttle lamb, li - ttle lamb, li - ttle lamb.

Ma - ry had a li - ttle lamb. It's fleece was white as snow

Uses notes F G A Bb C

Lightly Row

C A A Bb G G F G A Bb C C C C A A Bb G G

F A C C A G G G G G A Bb A A A A

A Bb C C A A Bb G G F A C C F

Uses notes F G A Bb C

Ode to Joy

A A Bb C C Bb A G F F G A A G G A A Bb C C Bb A G

F F G A G F F G A F G A Bb A F G A Bb A A G

F G C A A A Bb C C Bb A G F F G A G F F

Uses notes F G A Bb C

O When The Saints

O when the saints go mar-ching in. O when the saints go mar - ching in. We will all be in that num - ber when the saints go mar - ching in

Hot Cross Buns

Uses Notes: F G A

Hot cross buns. Hot cross buns. One a pen-ny, two a pen-ny. Hot cross buns.

Hot cross buns. Hot cross buns. One a pen-ny, two a pen-ny. Hot cross buns.

Jingle Bells

Uses Notes: F G A Bb C

Jin-gle bells. Jin-gle bells. Jin-gle all the way. Oh what fun it is to ride in a once horse o - pen sleigh, Hey! Jin - gle bells. Jin - gle bells. Jin - gle all the way. Oh what fun it is to ride in a once horse o - pen sleigh.

Oranges and Lemons

Uses Notes: F G A Bb C

Musical notation for 'Oranges and Lemons' in 3/4 time, featuring a treble clef and a key signature of one flat (Bb). The melody consists of 15 notes, each with a corresponding letter below it: C C A C A F G A Bb G C A F C C A C A F G A Bb G C A F.

Super Trooper

Uses Notes: F G A Bb C

Musical notation for 'Super Trooper' in 3/4 time, featuring a treble clef and a key signature of one flat (Bb). The melody consists of 15 notes, each with a corresponding letter below it: C C Bb Bb A G A Bb A G Bb Bb A A G Bb Bb A A G G G F G A G F F.

Vindaloo

Uses Notes: F G A Bb C

Musical notation for 'Vindaloo' in 3/4 time, featuring a treble clef and a key signature of one flat (Bb). The melody consists of 15 notes, each with a corresponding letter below it: A G F A G F A G F A G F A F G G A Bb A G A F F A G C A G F.

Incy Wincy Spider

Uses notes F G A Bb C

Musical notation for 'Incy Wincy Spider' in 3/4 time, featuring a treble clef and a key signature of one flat (Bb). The melody consists of 15 notes, each with a corresponding letter below it: C F F F G A A A G F G A F A A Bb C C Bb A Bb C A F F G A A G F G A F C F F F G A A A G F G A F.

The incy win-cy spi - der climbed up the wa - ter spout. Down came the rain and washed the spi - der out. Up came the sun and dried up all the rain. So in - cy win - cy spi - der climbed up the spout a - gain

Row, Row Row Your Boat

Uses Notes: F G A Bb C

F F F G A A G A Bb C
Row, row, row your boat, gen - tly down the stream.

F F F C C C A A A F F F C Bb A G F
Mer - ri - ly, mer - ri - ly, mer - ri - ly mer - ri - ly, life is but a dream

This is the Way We Wash Our Clothes

Uses Notes: F G A C

F F F F A C A F G G G F G C
This is the way we wash our clothes, wash our clothes, wash our clothes.

F F F F A C A F F G G C A G F F
This is the way we wash our clothes, so ear - ly i - n the mor - ning

The Old Gray Mare

Uses Notes: F G A C


C C F F F G A A G A G F G G F G F G
Oh, the old gray mare, she ain't what she used to be, ain't what she used to be,

A A G A G F C F F F G
ain't what she used to be. The old gray mare, she


A A G A G F G G G A G F
ain't what she used to be man - y long years a - go.

Hush, Little Baby

Uses Notes: G A B C



Musical notation for the first line of the song. The melody is written on a treble clef staff. The notes are: B (purple), B (purple), B (purple), B (purple), C (red), B (purple), A (purple), A (purple), A (purple), A (purple), A (purple), A (purple), B (purple), A (purple), G (teal), G (teal). The lyrics are: Hush, lit - tle ba - by, don't say a word. Ma-ma's gon-na buy you a mock - ing bird.



Musical notation for the second line of the song. The melody is written on a treble clef staff. The notes are: B (purple), B (purple), B (purple), C (red), B (purple), A (purple), A (purple), A (purple), A (purple), A (purple), A (purple), B (purple), A (purple), G (teal), G (teal). The lyrics are: If that mock - ing bird don't sing. Pa-pa's gon-na buy you a dia - mond ring.

For backing tracks, visit www.pbuzz.co.uk

Limited One-Year Warranty

Thank you for selecting your PBONE, PTRUMPET, PTRUMPET HYTECH, PBUZZ, PCORNET or PCOMPACT ("Product") manufactured by WARWICK MUSIC LIMITED ("Warwick Music").

Our Products are designed and manufactured to provide a high level of defect-free performance. We are proud of the experience and craftsmanship that goes into each and every instrument. Warwick Music sells its Products through a network of reputable, specially authorized dealers and is pleased to offer you the following Limited Warranty, which applies only to the Product that has been directly purchased from one of Warwick Music's authorized dealers.

If you have any problems, questions or want to offer feedback on any of our Products please email us makemusicfun@warwickmusic.com, call our UK-based Service Team on +44 2476 712081 or contact us via our Product websites or social media channels.

Limited Warranty

Warwick Music Limited ("Warwick Music") warrants to the original owner-user that this Product will be free from defects in material or workmanship. This warranty is limited to 12 months from the date of original purchase, whether or not actual use.

Limitations and Exclusions

Warranty inquiries must be made through an authorized Warwick Music dealer or arranged through our Warwick Music Customer Service team. Authorized returns must be shipped prepaid.

1. The warranty provided herein shall be void and of no effect in the event that:
 - a. The product has been operated outside its designed output capacity;
 - b. The problem is caused by improper, rough or careless treatment;
 - c. The problem is caused by a fire or other natural calamity;
 - d. The problem is caused by improper repair or adjustment made by

- anyone other than an approved Warwick Music repairer;
- e. The proof of purchase is not presented when requesting service; and/or
- f. The warranty period has expired.

2. The warranty provided herein is for replacement only. Warwick Music shall not be liable for any loss, cost, damage, or expense of any kind arising out of a breach of the warranty. Further, Warwick Music shall not be liable for any incidental, consequential, exemplary, special, or punitive damages, nor for any loss of revenue, profit or use, arising out of a breach of this warranty or in connection with the sale, maintenance, use, operation or repair of the Product. In no event will Warwick Music be liable for any amount greater than the purchase price of a defective product. The disclaimers of liability included shall remain in effect and shall continue to be enforceable in the event that any remedy herein shall fail of its essential purpose.
3. This warranty is the sole and exclusive warranty for the Product, and is in lieu of all other express and implied warranties. Warwick Music specifically disclaims all other express and implied warranties, including, but not limited to, all implied warranties of merchantability and fitness for a particular purpose.
4. This limited warranty gives you specific rights, and you may also have other rights which vary from state to state, jurisdiction to jurisdiction, or country to country. Nothing in this warranty affects your statutory rights.
5. No person or entity is authorized to bind Warwick Music to any other warranty, obligation or liability for any Product. Installation, operation or use of the Warwick Music Product for which this warranty is issued shall constitute acceptance of the terms hereof.